

MOTOMAN-MH5S / MH5F INSTRUCTIONS

TYPE: YR-MH0005S-A00 (STANDARD SPECIFICATION DX100)

YR-MH0005S-B00 (ARC SPECIFICATION DX100)

YR-MH0005F-A00 (STANDARD SPECIFICATION FS100)

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

MOTOMAN INSTRUCTIONS

MOTOVAN-MH5S / MH5F INSTRUCTIONS

DX100 INSTRUCTIONS

DX100 OPERATOR'S MANUAL

DX100 MAINTENANCE MANUAL

FS100 INSTRUCTIONS

FS100 OPERATOR'S MANUAL

FS100 MAINTENANCE MANUAL

The DX100 / FS100 Operator's manual above corresponds to specific usage.
Be sure to use the appropriate manual.

Part Number: 160475-1CD

Revision: 0



MANDATORY

- This instruction manual is intended to explain mainly on the mechanical part of the MOTOMAN-MH5S/MH5F for the application to the actual operation and for proper maintenance and inspection. It describes on safety and handling, details on specifications, necessary items on maintenance and inspection, to explain operating instructions and maintenance procedures. Be sure to read and understand this instruction manual thoroughly before installing and operating the manipulator.
- General items related to safety are listed in Chapter 1: Safety of the DX100 / FS100 Instructions. To ensure correct and safe operation, carefully read the DX100 / FS100 Instructions before reading this manual.



CAUTION

- Some drawings in this manual are shown with the protective covers or shields removed for clarity. Be sure all covers and shields are replaced before operating this product.
- The drawings and photos in this manual are representative examples and differences may exist between them and the delivered product.
- YASKAWA may modify this model without notice when necessary due to product improvements, modifications, or changes in specifications.
- If such modification is made, the manual number will also be revised.
- If your copy of the manual is damaged or lost, contact a YASKAWA representative to order a new copy. The representatives are listed on the back cover. Be sure to tell the representative the manual number listed on the front cover.
- YASKAWA is not responsible for incidents arising from unauthorized modification of its products. Unauthorized modification voids your product's warranty.

Notes for Safe Operation

Read this manual carefully before installation, operation, maintenance, or inspection of the MOTOMAN-MH5S/MH5F.

In this manual, the Notes for Safe Operation are classified as "WARNING", "CAUTION", "MANDATORY", or "PROHIBITED".



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury to personnel and damage to equipment. It may also be used to alert against unsafe practices.



MANDATORY

Always be sure to follow explicitly the items listed under this heading.



PROHIBITED

Must never be performed.

Even items described as "CAUTION" may result in a serious accident in some situations.

At any rate, be sure to follow these important items



To ensure safe and efficient operation at all times, be sure to follow all instructions, even if not designated as "CAUTION" and "WARNING".



WARNING

- Before operating the manipulator, check that servo power is turned OFF pressing the emergency stop buttons on the front door of the DX100 / F100 and the programming pendant. When the servo power is turned OFF, the SERVO ON LED on the programming pendant is turned OFF.

Injury or damage to machinery may result if the emergency stop circuit cannot stop the manipulator during an emergency. The manipulator should not be used if the emergency stop buttons do not function.

Fig. : Emergency Stop Button



- Once the emergency stop button is released, clear the cell of all items which could interfere with the operation of the manipulator. Then turn the servo power ON.

Injury may result from unintentional or unexpected manipulator motion.

Fig. : Release of Emergency Stop



- Observe the following precautions when performing teaching operations within the P-point maximum envelope of the manipulator:
 - View the manipulator from the front whenever possible.
 - Always follow the predetermined operating procedure.
 - Keep in mind the emergency response measures against the manipulator's unexpected motion toward you.
 - Ensure that you have a safe place to retreat in case of emergency.

Improper or unintended manipulator operation may result in injury.

- Confirm that no person is present in the P-point maximum envelope of the manipulator and that you are in a safe location before:
 - Turning ON the power for the DX100 / FS100.
 - Moving the manipulator with the programming pendant.
 - Running the system in the check mode.
 - Performing automatic operations.

Injury may result if anyone enters the P-point maximum envelope of the manipulator during operation. Always press an emergency stop button immediately if there is a problem.

The emergency stop buttons are located on the right of front door of the DX100 / FS100 and the programming pendant.



CAUTION

- Perform the following inspection procedures prior to conducting manipulator teaching. If problems are found, repair them immediately, and be sure that all other necessary processing has been performed.
 - Check for problems in manipulator movement.
 - Check for damage to insulation and sheathing of external wires.
- Always return the programming pendant to the hook on the cabinet of the DX100 / FS100 after use.

The programming pendant can be damaged if it is left in the manipulator's work area, on the floor, or near fixtures.

- Read and understand the Explanation of Warning Labels in the DX100 / FS100 Instructions before operating the manipulator:

Definition of Terms Used Often in This Manual

The MOTOMAN is the YASKAWA industrial robot product.

The MOTOMAN usually consists of the manipulator, the controller, the programming pendant, and supply cables.

In this manual, the equipment is designated as follows:

Equipment	Manual Designation
DX100 / FS100 controller	DX100 / FS100
DX100 / FS100 programming pendant	Programming pendant
Cable between the manipulator and the controller	Manipulator cable


Explanation of Warning Labels

The following warning labels are attached to the manipulator.

Always follow the warnings on the labels.

Also, an identification label with important information is placed on the body of the manipulator. Prior to operating the manipulator, confirm the contents.

Fig. : Warning Label Locations



Nameplate

YASKAWA MOTOMAN	
MODEL MOTOMAN- TYPE	
PAYLOAD	MASS
ORDER NO.	DATE
SERIAL NO.	
YASKAWA ELECTRIC CORPORATION 2-1 Kurosakishiroishi, Yahatanishi-ku, Kitakyushu 806-0004 Japan MADE IN JAPAN NJ3247	

WARNING Label A:



WARNING Label B:



1	Product Confirmation	1-1
1.1	Contents Confirmation	1-1
1.2	Order Number Confirmation	1-2
2	Transporting.....	2-1
2.1	Transporting Method.....	2-1
2.1.1	Using a Crane	2-2
2.1.2	Using a Forklift.....	2-3
2.2	Shipping Bolts and Brackets.....	2-4
3	Installation.....	3-1
3.1	Installation of the Safeguarding	3-2
3.2	Mounting Procedures for Manipulator Base	3-2
3.2.1	Mounting Example.....	3-3
3.3	Types of Mounting	3-4
3.3.1	S-Axis Operating Range.....	3-4
3.3.2	Fixing the Manipulator Base.....	3-4
3.3.3	Precautions to Prevent the Manipulator from Falling.....	3-4
3.4	Location	3-5
4	Wiring.....	4-1
4.1	Grounding.....	4-1
4.2	Cable Connection	4-2
4.2.1	Connection to the Manipulator.....	4-2
4.2.2	Connection to the DX100/FS100.....	4-3
5	Basic Specifications.....	5-1
5.1	Basic Specifications.....	5-1
5.2	Part Names and Working Axes.....	5-2
5.3	Baseplate Dimensions.....	5-2
5.4	Dimensions and P-Point Maximum Envelope.....	5-3
6	Allowable Load for Wrist Axis and Wrist Flange	6-1
6.1	Allowable Wrist Load	6-1
6.2	Wrist Flange.....	6-2
7	System Application	7-1

7.1	Peripheral Equipment Mounts.....	7-1
7.1.1	Allowable Load	7-1
7.2	Internal User I/O Wiring Harness and Air Lines.....	7-2
8	Electrical Equipment Specification	8-1
8.1	Internal Connections.....	8-1
9	Maintenance and Inspection	9-1
9.1	Inspection Schedule.....	9-1
9.2	Notes on Maintenance Procedures.....	9-6
9.2.1	Battery pack Replacement.....	9-6
9.3	Notes on Grease Replenishment/Exchange Procedures	9-8
9.3.1	Grease Replenishment for S-Axis Speed Reducer	9-9
9.3.1.1	Grease Replenishment (Refer to <i>fig. 9-4 "S-Axis Speed Reducer Diagram"</i> .)	9-9
9.3.2	Grease Replenishment for S-Axis Gear	9-10
9.3.2.1	Grease Replenishment (Refer to <i>fig. 9-5 "S-Axis Gear Diagram"</i> .)	9-10
9.3.3	Grease Replenishment for L-Axis Speed Reducer.....	9-11
9.3.3.1	Grease Replenishment (Refer to <i>fig. 9-6 "L-Axis Speed Reducer Diagram"</i> .)	9-11
9.3.4	Grease Replenishment for U-Axis Speed Reducer	9-12
9.3.4.1	Grease Replenishment (Refer to <i>"fig. 9-7 "U-Axis Speed Reducer Diagram"</i> .).....	9-12
9.3.5	Grease Replenishment for R-Axis Speed Reducer	9-13
9.3.5.1	Grease Replenishment (Refer to <i>fig. 9-8 "R-Axis Speed Reducer Diagram"</i> .).....	9-13
9.3.6	Grease Replenishment for B- and T-Axes Speed Reducers.....	9-14
9.3.6.1	Grease Replenishment for B-axis (Refer to <i>"fig. 9-9 "B- and T-Axes Speed Reducers Diagram"</i> .)	9-14
9.3.6.2	Grease Replenishment for T-axis (Refer to <i>fig. 9-9 "B- and T-Axes Speed Reducers Diagram"</i> .).....	9-15
9.3.7	Notes for Maintenance.....	9-16
9.3.7.1	Wrist Unit.....	9-16
9.3.7.2	Battery Pack Connector (with CAUTION label).....	9-16
10	Recommended Spare Parts.....	10-1

11	Parts List.....	11-1
11.1	S-Axis Unit.....	11-1
11.2	L-, U-Axes Unit	11-4
11.3	R-Axis Unit.....	11-7
11.4	Wrist Unit	11-9

1 Product Confirmation



CAUTION

- Confirm that the manipulator and the DX100/FS100 have the same order number. Special care must be taken when more than one manipulator is to be installed.

If the numbers do not match, manipulators may not perform as expected and cause injury or damage.

1.1 Contents Confirmation

Confirm the contents of the delivery when the product arrives.

Standard delivery includes the following four (six or seven) items
(Information for the content of optional goods is given separately):

DX100 Packing contents

- Manipulator
- DX100 (I include a spare)
- Programing Pendant
- Manipulator cables (between the DX100 and the manipulator)
- Manual


FS100 Packing contents

- Manipulator
- FS100 (I include a spare)
- Manipulator cables (between the FS100 and the manipulator)
- Manual
- Programing Pendant (Option)
- Programing Pendant Dummy connector (Option)

1.2 Order Number Confirmation

Check that the order number of the manipulator corresponds to the DX100/FS100. The order number is located on a label as shown below.

Fig. 1-1: Location of Order Number Labels



2 Transporting



CAUTION

- Sling applications and crane or forklift operations must be performed by authorized personnel only.
Failure to observe this caution may result in injury or damage.
- Avoid excessive vibration or shock during transportation.
The system consists of precision components. Failure to observe the caution may adversely affect performance.

2.1 Transporting Method




- Check that the eyebolts are securely fastened.
- The weight of the manipulator is approximately 27kg including the shipping bolts and brackets. Use a wire rope strong enough to withstand the weight.
- Attached eyebolts are designed to support the manipulator mass. Do not use them for anything other than transporting the manipulator.
- Mount the shipping bolts and brackets for transporting the manipulator.
- Avoid putting external force on the arm or motor unit when transporting by a crane, forklift, or other equipment. Failure to observe this instruction may result in injury.

2.1.1 Using a Crane

As a rule, the manipulator should be lifted by a crane with two wire ropes when removing it from the package and moving it.

Be sure the manipulator is fixed with the shipping bolts and brackets before transport, and lift it in the posture as shown in "fig. 2-1
"Transporting Position"".

Fig. 2-1: Transporting Position




2.1.2 Using a Forklift

When using a forklift, the manipulator should be fixed on a pallet with shipping bolts and brackets as shown in *fig. 2-2 "Using a Forklift"*. Insert claws under the pallet and lift it. The pallet must be strong enough to support the manipulator.

Transport the manipulator slowly with due caution in order to avoid overturning or slippage.

Fig. 2-2: Using a Forklift



MH5S/MH5F	2	Transporting
	2.2	Shipping Bolts and Brackets

2.2 Shipping Bolts and Brackets

The manipulator is equipped with shipping bolts and brackets at A and B as shown in *fig. 2-1 "Transporting Position" at page 2-2* to minimize external force during the transportation.

- The shipping bolts and brackets are painted yellow



Before turning ON the power, make sure that the shipping bolts and brackets are removed. The shipping bolts and brackets then must be stored for future use, in the event that the manipulator must be moved again.

Position	Bolt Type	Pcs
A	Hexagon socket head cap screw M6 (length: 20 mm) (tensile strength: 1200 N/mm ² or more)	2
B	Hexagon socket head cap screw M5 (length: 14 mm) (tensile strength: 1200 N/mm ² or more)	6

3 Installation



WARNING

- Install the safeguarding.

Failure to observe this warning may result in injury or damage.

- Install the manipulator in a location where the tool or the workpiece held by its fully extended arm will not reach the wall, safeguarding, or controller.

Failure to observe this warning may result in injury or damage.

- Do not start the manipulator or even turn ON the power before it is firmly anchored.

The manipulator may overturn and cause injury or damage.

- When mounting the manipulator on the ceiling or wall, the base section must have sufficient strength and rigidity to support the weight of the manipulator. Also, it is necessary to consider countermeasures to prevent the manipulator from falling.

Failure to observe these warnings may result in injury or damage.



CAUTION

- Do not install or operate a manipulator which is damaged or lacking parts.

Failure to observe this caution may cause injury or damage.

- Before turning on the power, check to be sure that the shipping bolts and brackets explained in *fig. 2-1 "Transporting Position"* at *page 2-2* are removed.

Failure to observe this caution may result in damage to the driving parts.

	3	Installation
MH5S/MH5F	3.1	Installation of the Safeguarding

3.1 Installation of the Safeguarding

To insure safety, be sure to install safeguarding. They prevent unforeseen accidents with personnel and damage to equipment. The following is quoted for your information and guidance.

Responsibility for Safeguarding (ISO10218)

The user of a manipulator or robot system shall ensure that safeguarding is provided and used in accordance with Sections 6, 7, and 8 of this standard. The means and degree of safeguarding, including any redundancies, shall correspond directly to the type and level of hazard presented by the robot system consistent with the robot application. Safeguarding may include but not be limited to safeguarding devices, barriers, interlock barriers, perimeter guarding, awareness barriers, and awareness signals.

3.2 Mounting Procedures for Manipulator Base

The manipulator should be firmly mounted on a baseplate or foundation strong enough to support the manipulator and withstand repulsion forces during acceleration and deceleration.

Construct a solid foundation with the appropriate thickness to withstand maximum repulsion forces of the manipulator as shown in *table 3-1 "Maximum Repulsion Forces of the Manipulator at Emergency Stop"* and *table 3-2 "Endurance torque in Operation"*.

The flatness for installation must be kept at 0.5 mm or less: if the flatness of the mounting face is insufficient, the manipulator shape may change and its functional ability may be compromised. Mount the manipulator base as shown in *chapter 3.2.1 "Mounting Example" at page 3-3* in principle.

Table 3-1: Maximum Repulsion Forces of the Manipulator at Emergency Stop

Horizontal rotating maximum torque (S-axis moving direction)	700 N • m (71.4 kgf • m)
Vertical rotating maximum torque (LU-axis moving direction)	700 N • m (71.4 kgf • m)

Table 3-2: Endurance torque in Operation

Endurance torque in horizontal operation (S-axis moving direction)	220 N • m (22.4 kgf • m)
Endurance torque in vertical operation (LU-axes moving direction)	270 N • m (27.6 kgf • m)

3.3 Types of Mounting

The MOTOMAN-MH5S / MH5F is available in three types: floor-mounted type (standard), wall-mounted type, and ceiling-mounted type. For wall-mounted and ceiling-mounted types, the three points listed below are different from the floor-mounted type.

- S-axis Operating Range
- Fixing of the Manipulator Base
- Precautions to Prevent the Manipulator from Falling

3.3.1 S-Axis Operating Range

For the wall-mounted type, the S-axis movable range is $\pm 30^\circ$.
(The range is adjusted prior to the shipment.)


3.3.2 Fixing the Manipulator Base

For the wall- and ceiling-mounted types, be sure to use four hexagon socket head cap screws M10 (tensile strength: 1200 N/mm² or more) when fixing the manipulator base. Use a torque of 48 N·m when tightening the screws.

3.3.3 Precautions to Prevent the Manipulator from Falling

For the wall- or ceiling-mounted types, take appropriate measures to avoid the falling of the manipulator in case of emergency. Refer to *fig. 3-2 "Precaution Against Falling"* for details.

Fig. 3-2: Precaution Against Falling



In case of using the wall-/ceiling-mounted type, inform Yaskawa of the matter when placing an order. Be sure to contact Yaskawa representative (listed on the back cover of this instruction manual) to execute a wall/ceiling installation on site.

MH5S/MH5F

3 Installation
3.4 Location

3.4 Location

When installing the manipulator, it is necessary to satisfy the following environmental conditions:

- Ambient Temperature: 0° to +45°C
- Humidity: 20 to 80%RH (non-condensing)
- Free from dust, soot, oil, or water
- Free from corrosive gas or liquid, or explosive gas or liquid.
- Free from excessive vibration
(Vibration acceleration: 4.9m/s² [0.5G] or less)
- Free from large electrical noise (plasma)
- Flatness for installation: 0.5mm or less

4 Wiring



WARNING

- Ground resistance must be 100 Ω or less.

Failure to observe this warning may result in fire or electric shock.

- Before wiring, make sure to turn the primary power supply OFF, and put up a warning sign. (ex. DO NOT TURN THE POWER ON.)

Failure to observe this warning may result in fire or electric shock.



CAUTION

- Wiring must be performed by authorized or certified personnel.

Failure to observe this caution may result in fire or electric shock.

4.1 Grounding


Follow the electrical installation standards and wiring regulations for grounding. A ground wire of 5.5 mm² or more is recommended.

Refer to *fig. 4-1 "Grounding Method"* at *page 4-2* to connect the ground line directly to the manipulator.



- Never use this wire sharing with other ground lines or grounding electrodes for other electric power, motor power, welding devices, etc.
- Where metal ducts, metallic conduits, or distributing racks are used for cable laying, ground in accordance with electrical installation standards.

Fig. 4-1: Grounding Method



4.2 Cable Connection

Two manipulator cables are delivered with the manipulator; an encoder cable (1BC) and a power cable (2BC). (Refer to *fig. 4-2(a) "Manipulator Cables for DX100"* at page 4-3 and *fig. 4-2(b) "Manipulator Cables for FS100"* at page 4-4.)

Connect the cables to the manipulator base connectors and to the DX100/FS100. Refer to *fig. 4-3(a) "Manipulator Cable Connection (Manipulator Side)"* at page 4-5, *fig. 4-3(b) "Manipulator Cable Connection (DX100 Side)"* at page 4-5 and *fig. 4-3(c) "Manipulator Cable Connection (FS100 Side)"* at page 4-6

4.2.1 Connection to the Manipulator

Before connecting cables to the manipulator, verify the numbers on both the manipulator cables and the connectors on the connector base of the manipulator. When connecting, adjust the cable connector positions to the main key positions of the manipulator, and insert cables in the order of 2BC, then 1BC. After inserting the cables, depress the lever until they click.

4.2.2 Connection to the DX100/FS100

Before connecting cables to the DX100/FS100, verify the numbers on both manipulator cables and the connectors on the DX100/FS100.

- DX100
When connecting, insert the cables in the order of X21, then X11, and depress each lever low until they click.
- FS100
After connecting 2BC to X21 on the FS100, connect 1BC to X11 on the FS100 and depress each lever low until they click.

Fig. 4-2(a): Manipulator Cables for DX100




Fig. 4-2(b): Manipulator Cables for FS100




Fig. 4-3(a): Manipulator Cable Connection (Manipulator Side)






Fig. 4-3(b): Manipulator Cable Connection (DX100 Side)*Fig. 4-3(c): Manipulator Cable Connection (FS100 Side)*

Details of Power Supply Ccable Cconnector
(The NXC100 Side)

5 Basic Specifications

5.1 Basic Specifications

Table 5-1: Basic Specifications¹⁾

Item	Model	MOTOMAN-MH5S / MH5F
Application		Handling
Structure		Vertically Articulated
Degree of freedom		6
Payload		5 kg
Repeatability ²⁾		±0.02 mm
Range of Motion	S-Axis (turning)	-170° ~ +170°
	L-Axis (lower arm)	-65° ~ +150° ³⁾
	U-Axis (upper arm)	-136° ~ +255° ³⁾
	R-Axis (wrist roll)	-190° ~ +190° ³⁾
	B-Axis (wrist pitch/yaw)	-135° ~ +135°
	T-Axis (wrist twist)	-360° ~ +360°
Maximum Speed	S-Axis	6.56 rad/s, 376° /s
	L-Axis	6.11 rad/s, 350° /s
	U-Axis	6.98 rad/s, 400° /s
	R-Axis	7.85 rad/s, 450° /s
	B-Axis	7.85 rad/s, 450° /s
	T-Axis	12.57 rad/s, 720° /s
Allowable Moment ⁴⁾	R-Axis	12 N•m (1.22 kgf•m)
	B-Axis	12 N•m (1.22 kgf•m)
	T-Axis	7 N•m (0.71 kgf•m)
Allowable Inertia (GD ²) ⁴⁾	R-Axis	0.30 kg•m ²
	B-Axis	0.30 kg•m ²
	T-Axis	0.10 kg•m ²
Approx. Mass		27 kg
Ambient Conditions	Temperature	0 to 45°C
	Humidity	20 to 80% RH (non-condensing)
	Vibration	4.9 m/s ² (0.5G) or less
	Others	Free from corrosive gas or liquid, or explosive gas Free from dust, soot, or water Free from excessive electrical noise (plasma)
Power Capacity		1 kVA

1) SI units are used in this table. However, gravitational unit is used in ()


2) Conformed to ISO9283

3) Each L-, U- and R-axes has the limit of motion depending on the postures.

4) Refer to fig. 6-1 "Moment Arm Rating" at page 6-1 for details on the permissible moment of inertia.


5.2 Part Names and Working Axes

Fig. 5-1: Part Names and Working Axes




5.3 Baseplate Dimensions

Fig. 5-2: Manipulator Base Dimensions



5.4 Dimensions and P-Point Maximum Envelope

Fig. 5-3: Dimensions and P-Point Maximum Envelope (mm)



MH5S/MH5F

- 6 Allowable Load for Wrist Axis and Wrist Flange
 6.1 Allowable Wrist Load

6 Allowable Load for Wrist Axis and Wrist Flange

6.1 Allowable Wrist Load

The allowable wrist load is 5 kg maximum. If force is applied to the wrist instead of the load, force on R-, B-, and T-Axes should be within the value shown in *table 6-1 "Allowable Wrist Load"*. Contact your Yaskawa representative for further information or assistance.

Table 6-1: Allowable Wrist Load


Axis	Moment N•m (kgf•m) ¹	GD ² /4 Total Inertia kg•m ²
R-Axis	12 (1.22)	0.30
B-Axis	12 (1.22)	0.30
T-Axis	7 (0.71)	0.10

1 (): Gravitational unit

When the volume load is small, refer to the moment arm rating shown in *fig. 6-1 "Moment Arm Rating"*.

The allowable total inertia is calculated when the moment is at the maximum. Contact your Yaskawa representative beforehand when moment of inertia is the only load, or load moment is smaller than moment of inertia. Also contact your Yaskawa representative in advance in a case where the load mass is combined with an external force.

Fig. 6-1: Moment Arm Rating




	6	Allowable Load for Wrist Axis and Wrist Flange
MH5S/MH5F	6.2	Wrist Flange

6.2 Wrist Flange

The wrist flange dimensions are shown in *fig. 6-2 “Wrist Flange”*.
It is recommended that the attachment be mounted inside the fitting in order to identify the alignment marks. Fitting depth shall be 5 mm or less.

Fig. 6-2: Wrist Flange



Wash off anti-corrosive paint (yellow) on the wrist flange surface with thinner or light oil before mounting the tools.

	7	System Application
MH5S/MH5F	7.2	Internal User I/O Wiring Harness and Air Lines

7.2 Internal User I/O Wiring Harness and Air Lines

Internal user I/O wiring harness (16 wires :0.2 mm²) and two air lines are incorporated in the manipulator for the drive of the peripheral devices mounted on the upper arm as shown in *fig. 7-2 "Connectors for Internal User I/O Wiring Harness and Air Line"*.

The connector pins 1 to 16 are assigned as shown in *fig. 7-3 "Details of the Connector Pin Numbers"*. Wiring must be performed by users. conditions below:

The allowable current for internal user I/O wiring harness	2.5 A or less for each wire (The total current value for pins 1 to 16 must be 40 A or less.)
The maximum pressure for the air line	490 kPa (5 kgf/cm ²) or less (The air hose inside diameter: 4mm)

Fig. 7-2: Connectors for Internal User I/O Wiring Harness and Air Line





Fig. 7-3: Details of the Connector Pin Numbers



Internal User I/O Wiring Harness:
 0.2 mm² (10 wires, 6 wires)

The same pin-number connectors (1-16) at both connector base part and arm part are connected with the single wire lead of 0.2mm².

8 Electrical Equipment Specification

8.1 Internal Connections

High reliability connectors are equipped on each connection part of the manipulator to enable easy removal and installation for maintenance and inspection. For the number and location of connectors, see *fig. 8-1 "Locations and Numbers of Connectors"*.

Diagrams for internal connections of the manipulator are shown in *fig. 8-2(a) "Internal Connection Diagram for DX100 / FS100"* at page 8-2, *fig. 8-2(b) "Internal Connection Diagram for DX100 / FS100"* at page 8-3.

Fig. 8-1: Locations and Numbers of Connectors





Table 8-1: List of Connector Types

Name	Type of Connector
Connector for Internal User I/O Wiring Harness on the connector base	HR10A-10R-10P (HR10A-10P-10P*HIROSE*: Optional)
Connector for Internal User I/O Wiring Harness on the U-arm	HR10A-10R-10S (HR10A-10P-10S*HIROSE*: Optional)



Fig. 8-2(b): Internal Connection Diagram for DX100 / FS100



9 Maintenance and Inspection



WARNING

- Before maintenance or inspection, be sure to turn the main power supply OFF, and put up a warning sign. (ex. DO NOT TURN THE POWER ON.)

Failure to observe this warning may result in electric shock or injury.



CAUTION

- Maintenance and inspection must be performed by specified personnel.

Failure to observe this caution may result in electric shock or injury.

- For disassembly or repair, contact your Yaskawa representative.
- The battery pack must be connected before removing detection connector when maintenance and inspection.

Failure to observe this caution may result in the loss of home position data.

9.1 Inspection Schedule

Proper inspections are essential not only to assure that the mechanism will be able to function for a long period, but also to prevent malfunctions and assure safe operation. Inspection intervals are classified into six levels as shown in *table 9-1 "Inspection Items" at page 9-2*.

In *table 9-1 "Inspection Items" at page 9-2*, the inspection items are categorized by types of operations: operations which can be performed by personnel authorized by the user, operations to be performed by trained personnel, and operations to be performed by service company personnel. Only specified personnel shall perform the inspection work.



- The inspection interval must be based on the servo power supply on time.

- The following inspection schedule is based on the case where the manipulator is used for arc welding application. If the manipulator is used for other application or if it is used under special conditions, a case-by-case examination is required.

The inspection may be conducted at shorter intervals if the manipulator is used very frequently for the application such as handling, in this case, contact your Yaskawa representative.

MH5S/MH5F

9 Maintenance and Inspection
9.1 Inspection Schedule

Table 9-1: Inspection Items (Sheet 1 of 2)

Items ¹⁾	Schedule						Method	Operation	Inspection Charge		
	Daily	1000H Cycle	6000H Cycle	12000H Cycle	24000H	36000H			Specified Personnel	Licensee	Service Company
1	●						Visual	Check tram mark accordance and damage at the home position.	●	●	●
2	●						Visual	Clean the work area if dust or spatter is present. Check for damage and outside cracks.	●	●	●
3		●					Spanner Wrench	Tighten loose bolts. Replace if necessary.	●	●	●
4		●					Screwdriver, Wrench	Tighten loose bolts. Replace if necessary.	●	●	●
5		●					Manual	Check for loose connectors.	●	●	●
6			●				Visual Multimeter	Check for conduction between the main connector of base and intermediate connector with manually shaking the wire. Check for wear of protective spring ²⁾		●	●
					●			Replace ³⁾			●
7						●		Replace the battery pack when the battery alarm occurs or the manipulator drove for 36000H.		●	●
8			●				Grease Gun	Check for malfunction. (Replace if necessary.) Supply grease ⁴⁾ (6000H cycle). See chapter 9.3.1 at page 9-9		●	●
9			●				Grease Gun	Check for malfunction. (Replace if necessary.) Supply grease ⁴⁾ (6000H cycle). See chapter 9.3.3 at page 9-11 and chapter 9.3.4 at page 9-12.		●	●

Table 9-1: Inspection Items (Sheet 2 of 2)

Items ¹⁾	Schedule						Method	Operation	Inspection Charge		
	Daily	1000HCycle	6000HCycle	12000HCycle	24000H	36000H			Specified Personnel	Licensee	Service Company
10	R-axis speed reducer		●				Grease Gun	Check for malfunction. (Replace if necessary.) Supply grease ⁴⁾ (6000H cycle). See chapter 9.3.5 at page 9-13		●	●
11	BT-axes speed reducers T-axis gear		●				Grease Gun	Check for malfunction. (Replace if necessary.) Supply grease ⁴⁾ (6000H cycle). See chapter 9.3.6 at page 9-14		●	●
12	Overhaul					●					●

1

Inspection No. correspond to the numbers in fig. 9-1 "Inspection Items" at page 9-4.

2

When checking for conduction with multimeter, connect the battery to "BAT" and "OBT" of connectors on the motor side for each axis, and then remove connectors on detector side for each axis from the motor. Otherwise, the home position may be lost. (Refer to "9.2.7 Notes for Maintenance ")

3

Wire harness in manipulator (S-, L-, U-, R-, B-, T-axis part) to be replaced at 24000H inspection.

4

For the grease, refer to "Table. 8 Inspection Parts and Grease Used".

Fig. 9-1: Inspection Items




Table 9-2: Inspection Parts and Grease Used

No.	Grease Used	Inspected Parts
9,10,11, 12	Harmonic Grease SK-1A	S, L, U, R, B and T-axes speed reducers, T- and S-axes gears

The numbers in the above table correspond to the numbers in *table 9-1 "Inspection Items" at page 9-2.*

9.2 Notes on Maintenance Procedures

9.2.1 Battery pack Replacement

The battery packs are installed in the position shown in *fig. 9-2 "Battery Location"*.

If the battery alarm occurs in the DX100/FS100, replace the battery in accordance with the following procedure:

Fig. 9-2: Battery Location





Fig. 9-3: Battery Connection



1. Turn OFF the DX100/FS100 main power supply.
2. Remove the plate fastening screws and the plate on the connector base, then pull the battery pack put to replace it with the new one.
3. Remove the battery pack from the battery holder.
4. Connect the new battery pack to the unoccupied connectors on the board.
5. Remove the old battery pack from the board.



Remove the old battery pack after connecting the new one so that the encoder absolute data does not disappear.

6. Mount the new battery pack on the battery holder.
7. Reinstall the plate.



Do not allow plate to pinch the cables when reinstalling the plate.

9.3 Notes on Grease Replenishment/Exchange Procedures


Make sure to follow the instructions listed below at grease replenishment/exchange. Failure to observe the following notes may result in damage to motor and speed reducer.



- If grease is added without removing the plug/screw from the grease exhaust port, the grease will leak inside a motor or an oil seal of a speed reducer will come off, which may result in damage to the motor. Make sure to remove the plug/screw.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.
- Make sure to use a grease pump to inject grease. Set air supply pressure to the grease pump at 0.3 MPa or less, and the grease injection rate at 8 g/s or less.
- Make sure to fill hoses, which are joined to the grease inlet, with grease beforehand to prevent air from intruding into the speed reducer.

9.3.1 Grease Replenishment for S-Axis Speed Reducer

Fig. 9-4: S-Axis Speed Reducer Diagram



9.3.1.1 Grease Replenishment (Refer to fig. 9-4 "S-Axis Speed Reducer Diagram" .)

Replenish the grease in accordance with the following procedure:

1. Remove the hexagon socket head cap screw M6 from the grease inlet and the hexagon socket head plug PT1/8 from the exhaust port.

NOTE

- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is packed with the manipulator on the shipment.)
3. Inject the grease into the grease inlet using a grease gun.
 - Grease type: Harmonic Grease SK-1A
 - Amount of grease: 25cc


NOTE

The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

4. Move the S-axis for a few minutes to discharge excess grease.
5. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the screw M6, and the plug PT1/8 to the exhaust port.
Apply Three Bond 1206C on the thread part of the screw/plug.

9.3.2 Grease Replenishment for S-Axis Gear

Fig. 9-5: S-Axis Gear Diagram



9.3.2.1 Grease Replenishment (Refer to fig. 9-5 "S-Axis Gear Diagram" .)

Replenish the grease in accordance with the following procedure:

1. Remove the hexagon socket head plug PT1/8 from the grease inlet and from the exhaust port.



- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk PT1/8 to the grease inlet. (The grease zerk is packed with the manipulator on the shipment.)
3. Inject the grease into the grease inlet using a grease gun.
 - Grease type: Harmonic Grease SK-1A
 - Amount of grease: 25cc




The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

4. Move the S-axis for a few minutes to discharge excess grease.
5. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the plug PT1/8 to the grease inlet and to the exhaust port.
 Apply Three Bond 1206C on the thread part of the plug.

9.3.3 Grease Replenishment for L-Axis Speed Reducer

Fig. 9-6: L-Axis Speed Reducer Diagram



9.3.3.1 Grease Replenishment (Refer to fig. 9-6 “L-Axis Speed Reducer Diagram”.)

1. Remove the cover to unscrew the hexagon socket head cap screw M6 from the grease inlet and the plug M5 from the exhaust port.

NOTE

- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk A-MT6 x 1 to the grease inlet. (The grease zerk is packed with the manipulator on the shipment.)
3. Inject grease into the grease inlet using a grease gun.

- Grease type: Harmonic Grease SK-1A
- Amount of grease: 30cc


NOTE

The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

4. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the screw M6, and the plug M5 to the exhaust port before reinstalling the cover. Apply Three Bond 1206C on the thread part of the screw/plug.

9.3.4 Grease Replenishment for U-Axis Speed Reducer

Fig. 9-7: U-Axis Speed Reducer Diagram



9.3.4.1 Grease Replenishment (Refer to "fig. 9-7 "U-Axis Speed Reducer Diagram" .)

1. Remove the cover to unscrew hexagon socket head cap screw M6 from the grease inlet and the plug M5 from the exhaust port.



- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.

Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk A-MT6 x 1 to the grease inlet. (The grease zerk is packed with the manipulator on the shipment.)
3. Inject grease into the grease inlet using a grease gun.
 - Grease type: Harmonic Grease SK-1A
 - Amount of grease: 20cc




The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

4. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the screw M6, and the plug M5 to the exhaust port before reinstalling the cover. Apply Three Bond 1206C on the thread part of the screw/plug.

9.3.5 Grease Replenishment for R-Axis Speed Reducer

Fig. 9-8: R-Axis Speed Reducer Diagram



9.3.5.1 Grease Replenishment (Refer to fig. 9-8 "R-Axis Speed Reducer Diagram" .)

1. unscrew the plug M5 from exhaust port.



- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Inject grease into the grease inlet using a grease gun.

- Grease type: Harmonic Grease SK-1A
- Amount of grease: 7cc




The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

3. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the plug to the exhaust port. Apply Three Bond 1206C on the thread part of the plug.

9.3.6 Grease Replenishment for B- and T-Axes Speed Reducers

Fig. 9-9: B- and T-Axes Speed Reducers Diagram



9.3.6.1 Grease Replenishment for B-axis (Refer to "fig. 9-9 "B- and T-Axes Speed Reducers Diagram" .)

1. unscrew the plug M5 from the exhaust port.



- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Inject grease into the grease inlet using a grease gun.

- Grease type: Harmonic Grease SK-1A
- Amount of grease: 5cc



The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.

3. Wipe the discharged grease with a cloth. Reinstall the plug to the exhaust port.
Apply Three Bond 1206C on the thread part of the plug.

9	Maintenance and Inspection
9.3	Notes on Grease Replenishment/Exchange Procedures

9.3.6.2 Grease Replenishment for T-axis (Refer to *fig. 9-9 "B- and T-Axes Speed Reducers Diagram"*.)

1. Remove the plug M5 from the exhaust port and the low head socket head cap screw M6 from the grease inlet.



- If grease is injected with the plug on, the grease will leak inside the motor and may cause a damage. Make sure to remove the plug before the grease injection.
- Do not install a joint, a hose, etc. to the grease exhaust port. Failure to observe this instruction may result in damage to the motor due to coming off of an oil seal.

2. Install the grease zerk A-MT6 x 1 to the grease inlet. (The grease zerk is packed with the manipulator on the shipment.)
3. Inject grease into the grease inlet using a grease gun.
 - Grease type: Harmonic Grease SK-1A
 - Amount of grease: 5cc



The exhaust port is used for air exhaust, and the grease is not exhausted from the exhaust port. Do not inject excessive grease through the grease inlet.


4. Wipe the discharged grease with a cloth. Remove the grease zerk from the grease inlet and reinstall the screw M6, and the plug M5 to the exhaust port.
Apply Three Bond 1206C on the thread parts of the plug/screw.

9.3.7 Notes for Maintenance

9.3.7.1 Wrist Unit

The motor and encoder units are provided with the wrist unit. To prevent fumes from penetrating into the wrist unit, the jointed faces are sealed with sealing bond. If the wrist cover is disassembled, make sure to reseal with sealing bond (Three Bond 1206C, refer to *table 10-1 "Spare Parts for the YR-MH0005S-A00,B00/YR-MH0005F-A00"* at page 10-1.


Fig. 9-10: Sealing Part of Wrist Unit




9.3.7.2 Battery Pack Connector (with CAUTION label)

Before removing the encoder connector (with CAUTION label), connect the battery pack referring to the following figures.

Fig. 9-11: Encoder Connector Diagram (with CAUTION label)



CAUTION label (Enlarged view)



a: Crimped contact-pin (socket)
 b: Crimped contact-pin (pin)

10 Recommended Spare Parts

It is recommended to keep the parts and components in the following table in stock as spare parts for the MOTOMAN-MH5S/MH5F. Product performance cannot be guaranteed when using spare parts from any company other than Yaskawa. The spare parts are ranked as follows:

- Rank A: Expendable and frequently replaced parts
- Rank B: Parts for which replacement may be necessary as a result of frequent operation
- Rank C: Drive unit



For replacing parts in rank B or rank C, contact your Yaskawa representative.

Table 10-1: Spare Parts for the YR-MH0005S-A00,B00/YR-MH0005F-A00 (Sheet 1 of 2)

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
A	1	Grease	Harmonic Grease SK-1A	Harmonic Drive Systems Co., Ltd.	2.5 kg	-	
A	2	Liquid Gasket	Three Bond 1206C	Three Bond Co., Ltd.	-	-	
A	3	Battery Pack	HW0470360-A	Yaskawa Electric Corporation	1	1	
A	4	Battery Pack	HW9470932-A	Yaskawa Electric Corporation	1	1	
B	5	L-Axis Timing Belt	100S5M305	Mitsuboshi Belting Ltd.	1	1	
B	6	U-Axis Timing Belt	100S5M390	Mitsuboshi Belting Ltd.	1	1	
B	7	R-Axis Timing Belt	060S3M219	Mitsuboshi Belting Ltd.	1	1	
B	8	BT-Axis Timing Belt	060S3M396	Mitsuboshi Belting Ltd.	1	2	
B	9	S-Axis Speed Reducer	HW0389176-A	Yaskawa Electric Corporation	1	1	
B	10	L-Axis Speed Reducer	HW0388706-A	Yaskawa Electric Corporation	1	1	
B	11	U-Axis Speed Reducer	HW0388707-A	Yaskawa Electric Corporation	1	1	
B	12	R-Axis Speed Reducer	HW0388708-A	Yaskawa Electric Corporation	1	1	
B	13	B-Axis Speed Reducer	HW1380238-A	Yaskawa Electric Corporation	1	1	
B	14	T-Axis Speed Reducer	HW0388710-A	Yaskawa Electric Corporation	1	1	

10 Recommended Spare Parts

MH5S/MH5F


Table 10-1: Spare Parts for the YR-MH0005S-A00,B00/YR-MH0005F-A00 (Sheet 2 of 2)

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
B	15	Wire Harness in Manipulator	HW0175096-A	Yaskawa Electric Corporation	1	1	
C	16	S-and L-Axes AC Servomotor	HW0388651-A SGMAV-04ANA-YR1*	Yaskawa Electric Corporation	1	2	
C	17	U-Axis AC Servomotor	HW038650-A SGMAV-02ANA-YR1*	Yaskawa Electric Corporation	1	1	
C	18	R-Axis AC Servomotor	HW0388708-1 SGMAV-A5ANA-YR1*	Yaskawa Electric Corporation	1	1	
C	19	R- B-, and T-Axes AC Servomotor	HW0388794-A SGMAV-A5ANA-YR2*	Yaskawa Electric Corporation	1	2	
C	20	B-and T-Axes Brake	HW1470525	Yaskawa Electric Corporation	1	2	

11 Parts List

11.1 S-Axis Unit

Fig. 11-1: S-Axis Unit



MH5

11 Parts List
11.1 S-Axis Unit

Table 11-1: S-Axis Unit (Sheet 1 of 2)

No.	DWG No.	Name	Pcs
1001	HW0102487-1	Base	1
1002	HW0102486-1	S head	1
1003	HW0314329-1	Cover	1
1004	HW0314328-1	Cover	1
1005	HW0414024-1	Collar	1
1006	HW0414025-1	B holder	1
1007	HW0414034-1	M base	1
1008	HW0314319-1	Shaft	1
1009	HW0412383-1	Packing	1
1010	HW0414064-1	M base	1
1011	HW0314707-1	Gear	1
1012	HW0314708-2	Gear	1
1013	HW8411125-2	Washer	16
1014	HW0389176-A	Speed reducer	1
1015	6811LLU	Bearing	1
1016	6810VV	Bearing	1
1017	TC405208	Oil seal	1
1018	TC25X35X6FKM	Oil seal	1
1019	S39	O ring	1
1020	PT1/8	Plug	3
1021	HW9482404-A	Sheet	1
1022	POC6-01M	Union	1
1023	M4X10	Button bolt	22
1024	M8X16	Socket screw	1
1025	2H-8	Spring washer	1
1026	M6X8	Socket screw	1
1027	2H-6	Spring washer	1
1028	M5X16	Socket screw	1
1029	2H-5	Spring washer	1
1030	M4X25	Socket screw	2
1031	2H-4	Spring washer	2
1032	M4	Washer	4
1033	M3X30	Socket screw	6
1034	2H-3	Spring washer	6
1035	M4X14	Socket screw	2
1036	2H-4	Spring washer	2
1037	M5X40	Socket screw	12
1038	2H-5	Spring washer	12
1039	M5X30	Socket screw	16
1040	2H-5	Spring washer	16
1041	M4X10	GT-SA bolt	4
1043	M4X16	GT-SA bolt	7
1045	M4X12	GT-SA bolt	4

MH5	11	Parts List
	11.1	S-Axis Unit

Table 11-1: S-Axis Unit (Sheet 2 of 2)

No.	DWG No.	Name	Pcs
1047	SGMAV-04ANA-YR11	Motor	1
1048	HW0414483-1	Cover	1
1049	HW0414484-1	Packing	1


MH5

11 Parts List

11.2 L-, U-Axes Unit

11.2 L-, U-Axes Unit

Fig. 11-2: L-, U-Axes Unit



	11	Parts List
MH5	11.2	L-, U-Axes Unit

Table 11-2: L-, U-Axes Unit (Sheet 1 of 2)

No.	DWG No.	Name	Pcs
2001	HW0102585-1	L arm	1
2002	HW0414073-A	Pulley	1
2003	HW0414072-A	Pulley	1
2004	HW0414070-B	Pulley	1
2007	HW0414071-B	Pulley	1
2010	HW8411125-1	Collar	2
2011	HW0408927-2	Housing	1
2012	HW0408928-2	Housing	1
2013	HW0408931-1	Housing	2
2014	HW0388707-B	Speed reducer	1
2015	HW0388706-B	Speed reducer	1
2016	6913DDU	Bearing	1
2017	6000ZZ	Bearing	4
2018	6913ZZ	Bearing	2
2019	6916DDU	Bearing	1
2020	100S5M305	Belt	1
2021	100S5M390	Belt	1
2022	SC901107	Oil seal	1
2023	SC751007	Oil seal	3
2024	LP-M5	Plug	2
2025	SGMAV-04ANA-YR11	Motor	1
2026	SGMAV-02A2A-YR11	Motor	1
2027	HW0200555-1	Cover	1
2028	HW0200555-2	Cover	1
2029	HW0414027-1	M base	1
2030	M5X10	Button bolt	20
2031	M8X16	Socket screw	2
2032	2H-8	Spring washer	2
2033	M4X14	Socket screw	16
2034	2H-4	Spring washer	16
2035	M3X10	Socket screw	32
2036	2H-3	Spring washer	32
2037	M4X10	GT-SA bolt	4
2038	M4X16	GT-SA bolt	4
2039	M4X18	Socket screw	2
2040	2H-4	Spring washer	2
2041	M4	Washer	4
2042	M5X16	Socket screw	1
2043	2H-5	Spring washer	1
2044	M4X10	GT-SA bolt	4
2046	M5X20	Socket screw	1
2047	2H-5	Spring washer	1
2048	M6X8	Socket screw	1
2049	M4X12	Socket screw	29

MH5


11 Parts List
11.2 L-, U-Axes Unit

Table 11-2: L-, U-Axes Unit (Sheet 2 of 2)

No.	DWG No.	Name	Pcs
2050	CDW4L	Spring washer	29
2051	M4X16	Socket screw	30
2052	2H-4	Spring washer	30
2053	M4X10	GT-SA bolt	12
2055	M4X16	GT-SA bolt	8
2057	M4	Washer	8
2058	M8X16	Socket screw	2
2059	2H-8	Spring washer	2
2060	HW0414027-2	M base	1
1002	HW0102486-1	S head	1

11.3 R-Axis Unit

Fig. 11-3: R-Axis Unit



MH5

11 Parts List
11.3 R-Axis Unit

Table 11-3: R-Axis Unit

No.	DWG No.	Name	Pcs
3001	HW0102484-1	Casing	1
3002	HW0314334-1	Housing	1
3003	HW0414074-A	Pulley	1
3004	HW0483421-B	Pulley	1
3005	HW9406285-E	Pipe	1
3006	HW9406278-2	Washer	1
3007	HW0388708-A	Speed reducer	1
3008	6808ZZ	Bearing	1
3009	6806ZZ	Bearing	1
3010	060S3M219	Belt	1
3011	SGMAV-A5ANA-YR11	Motor	1
3012	OB-31	Plug	1
3013	M4X10	Button bolt	4
3014	M3X12	GT-SA bolt	2
3016	M3X12	GT-SA bolt	2
3018	M3	Washer	2
3019	M3X10	GT-SA bolt	3
3021	M3X30	Socket screw	12
3022	2H-3	Spring washer	12
3023	M6X16	Socket screw	4
3024	2H-6	Spring washer	4
3025	M3X20	Socket screw	16
3026	2H-3	Spring washer	16
3027	M3X12	Socket screw	1
3028	2H-3	Spring washer	1
3029	HW0201198-1	Cover	1
3030	LP-M5	Plug	1
2001	HW0102485-1	L arm	1

MH5

11 Parts List
11.4 Wrist Unit

Table 11-4: Wrist Unit (Sheet 1 of 2)

No.	DWG No.	Name	Pcs
4001	HW0102483-1	U arm	1
4002	HW0313997-1	Wrist base	1
4003	HW0388712-A	Gear	1
4004	HW0388711-A	Gear	1
4005	HW0414075-A	Pulley	2
4006	HW0414076-A	Pulley	1
4007	HW0414078-A	Pulley	1
4008	HW9406260-1	Housing	1
4009	HW9406266-1	B nut	1
4010	HW0414031-1	Collar	1
4011	HW0388709-A	Speed reducer	1
4012	HW0388710-A	Speed reducer	1
4013	HW9480739-B	Bearing	1
4014	6903ZZ	Bearing	4
4015	6809ZZ	Bearing	1
4016	TC56665	Oil seal	2
4017	AB2551E0	Oil seal	1
4018	SC20304	Oil seal	2
4019	060S3M300	Belt	1
4020	060S3M285	Belt	1
4021	S31.5	O ring	1
4022	S56	O ring	1
4023	HW0201199-1	Cover	2
4024	HW0314324-1	Shaft	1
4025	HW0314348-1	Housing	1
4026	HW0414067-1	Flange	1
4027	HW0414065-1	B holder	1
4028	HW0414066-1	Housing	1
4029	HW0414032-1	Collar	1
4030	HW0314333-1	M base	1
4031	HW0414028-1	B nut	1
4032	HW0414079-1	M base	2
4033	6803ZZ	Bearing	2
4034	6810VV	Bearing	1
4035	RTW-30	Retaining rings	1
4036	IRTW-26	Retaining rings	1
4037	LP-M5	Plug	5
4038	SPS-010005	Shim	1
4039	SP-009010	Shim	1
4040	SP-009015	Shim	1
4041	SP-009020	Shim	1
4042	M4X10	Button bolt	18
4043	M4X20	Socket screw	1
4044	2H-4	Spring washer	1

11 Parts List
 MH5 11.4 Wrist Unit

Table 11-4: Wrist Unit (Sheet 2 of 2)

No.	DWG No.	Name	Pcs
4045	M3X10	Socket screw	6
4046	2H-3	Spring washer	6
4047	M4X10	GT-SA bolt	6
4048	M3X12	Socket screw	6
4049	2H-3	Spring washer	6
4050	M4X20	Socket screw	1
4051	2H-4	Spring washer	1
4052	M3X16	Socket screw	2
4053	2H-3	Spring washer	2
4054	M4X16	GT-SA bolt	6
4056	M4	Washer	6
4057	M4X16	Socket screw	8
4059	M3X10	GT-SA bolt	2
4060	M4X10	GT-SA bolt	6
4062	M3X12	GT-SA bolt	10
4064	M3	Washer	4
4065	M4X10	GT-SA bolt	4
4067	CBSTS6-6	Socket screw	1
4068	SGMAV-A5ANA-YR21	Motor	2
4069	HW0414026-1	Housing	1
4070	HW0314323-1	Housing	2
4071	HW0414080-1	B holder	2
4072	HW0414077-A	Pulley	2
4075	HW0414030-1	Shaft	2
4076	HW0472643-A	Break	2
4080	6000ZZ	Bearing	4
4081	060S3M150	Belt	2
4082	STW-8	Retaining rings C-type	2
4083	M3X12	GT-SA bolt	4
4085	M3	Washer	4
4086	M3X10	GT-SA bolt	8
4089	M4X12	Socket screw	2
4090	2H-4	Spring washer	2
4091	M2.5X25	Socket screw	6
4092	HW0414829-1	Shim	2
4093	HW0414829-2	Shim	2
4094	HW0414829-3	Shim	2
4095	HW0414824-1	Cover	1
4096	HW0414825-1	Cover	1
4097	M4X6	Socket screw	2
4098	2H-4	Spring washer	2
3007	HW0388708-A	Speed reducer	1

MOTOMAN-MH5S / MH5F

INSTRUCTIONS

HEAD OFFICE

2-1 Kurosakishiroishi, Yahatanishi-ku, Kitakyushu 806-0004 Japan
Phone +81-93-645-7745 Fax +81-93-645-7746

YASKAWA America Inc. MOTOMAN Robotics Division
805 Liberty Lane, West Carrollton, OH 45449, U.S.A.
Phone +1-937-847-6200 Fax +1-937-847-6277

YASKAWA Nordic AB
Verkstadsgatan 2, PO Box 504, SE-385 25 Torsås, Sweden
Phone +46-480-417-800 Fax +46-486-414-10

YASKAWA Europe GmbH Robotics Div.
Kammerfeldstr. 1, 80591 Allershausen, Germany
Phone +49-8166-90-0 Fax +49-8166-90-103

YASKAWA Electric Korea Co., Ltd
9F, KYOBO Securities Bldg., 26-4, Yeoido-Dong Yeoungseongpo-ku, Seoul, KOREA
Phone +82-2-784-7844 Fax +82-2-784-8495

YASKAWA Electric (Singapore) PTE Ltd.
151 Lorong Chuan, #04-02A, New Tech Park, Singapore 556741
Phone +65-6282-3003 Fax +65-6289-3003

YASKAWA Electric (Thailand) Co., Ltd.
252/246, 4th Floor, Muang Thai-Phatra Office Tower II Rachadaphisek Road, Huaykwang Bangkok, 10320 Thailand
Phone +66-2-693-2200 Fax +66-2-693-4200

Shougang MOTOMAN Robot Co. Ltd.
No.7, Yongchang-North Road, Beijing E&T Development Area, China 100176
Phone +86-10-6788-0548 Fax +86-10-6788-0548-813

YASKAWA ELECTRIC (SHANGHAI) Co., Ltd.
No.18Xizang Zhong Road, 17F, Harbour Ring Plaza, Shanghai 200001, CHINA
Phone +86-21-5385-0655 Fax +86-21-5385-2770

YASKAWA Robotics India Ltd.
#426, Udyog Vihar, Phase- IV, Gurgaon, Haryana, India
Phone +91-124-475-8500 Fax +91-124-414-8016

Specifications are subject to change without notice
for ongoing product modifications and improvements.